

# CONTOUR CONSOLE

Patented Product



YOU HAVE ORDERED ONE OF THE FOLLOWING CONSOLES:		
Qty	Order #	Description
1	425-6018	10.5" Contour Console w/ Climate Control - Crown Victoria (425-6007)
1	425-6025	12" Contour Console w/ Climate Control - Crown Victoria (425-6027)

**PLUS**

Qty	Part #	Description
1	425-6023	28" Extruded "No Holes" Floor Plate Kit
1	425-1571-00	Adjustable leveler guide
20	000-1449	Phillips screws
10.5"-12"		Requested Faceplates

## CONTOUR CONSOLE W/ CLIMATE CONTROL INSTALLATION INSTRUCTIONS (Contour Console with faceplates & floor plate)

- STEP 1:** Check to see that you have all of the parts listed above.
- STEP 2:** Remove front inside driver and passenger seat rail bolts and loosen respective outside seat bolts.
- STEP 3:** Place floor plate legs, 425-6580, assembled with the upper portion, 425-6577, underneath seat rails and align leg holes with seat rail holes.  
*NOTE: Loosening the two nuts attaching the leg pieces together allows for height adjustment of floor plate.*
- STEP 4:** Screw leveler, 425-1571-00, through bottom of floor plate till post is flush on top. Place floor plate between seats with the leveler at the back.
- STEP 6:** Remove ash tray assembly.
- STEP 7:** Remove dash trim piece that surrounds the vehicles climate control. Start at right side of dash and gently pull. *(Dash piece has alignment tabs and insert snaps about every eight inches)*
- STEP 8:** Remove the four 7mm screws that secure the climate controls.
- STEP 9:** Remove climate control knobs. Disconnect just enough cables to slide through trim. Slide climate controls out and through the hole in the dash trim piece. There is no need to disconnect or cut the vacuum lines.
- STEP 10:** Replace trim piece by lining up the trim with the dash alignment tabs and insert snaps. *(Snap in place starting at the driver's side working towards the passenger door)*
- STEP 11:** Insert hex head bolts into the outside slots on top of the floor plate, two on each side. (They are used to secure the console to floor plate)
- STEP 12:** Place your console on top of the floor plate, with bolts (step 11) inserted through slots located at the bottom of the console. Slide the console till it is about a foot from the dash.
- STEP 13:** Align the four climate control bolt holes with the four threaded posts on the upper inside of the console. Push the climate control onto the posts until snug against the back of the console. Thread square bolts onto posts to keep controls in place.  
*NOTE: With some year models of the Crown Victoria, you'll find that the upper right bolt hole is not uniform with the others. Simply snip the matching post from the console and the controls will easily slide onto the console.*
- STEP 14:** Slide console up against the dash. *(upper left side of console has an alignment tab that inserts into the opening where the controls were)*
- STEP 13:** Using provided washers and nylock nuts, secure console to the floor plate.
- STEP 14:** Feed communications wiring through the back of the console.
- STEP 15:** Mount communications equipment to provided faceplates, connect wires to the equipment and attach to the front of console with screws.

## CONTOUR CONSOLE W/ CLIMATE CONTROL INSTALLATION INSTRUCTIONS (Contour Console with faceplates only)

- STEP 1:** Check to see that you have all of the parts listed.
- STEP 2:** Remove ash tray assembly.
- STEP 3:** Follow steps 7-10 & 13-14
- STEP 4:** Mount Console to your mounting surface as desired.
- STEP 5:** Mount communications equipment to provided faceplates, connect wires to equipment and attach to the front of the console with screws.

YOU HAVE ORDERED ONE OF THE FOLLOWING CONSOLES:		
Qty	Order #	Description
1	425-6007	10.5" Contour Console w/ Climate Control - Crown Victoria
1	425-6027	12" Contour Console w/ Climate Control - Crown Victoria

**PLUS**

Qty	Part #	Description
20	000-1449	Phillips screws
10.5"-12"	requested	Faceplates