



425-6460
'14+ Caprice
9C1 Contour Console
Installation Instructions



Loosely attach flange nuts to carriage bolts.



Slide the carriage bolts into slots of OEM console.



Place Contour Console on top of OEM console. Slide Contour Console snugly against the OEM dash.



Secure Contour Console in place by sliding previously positioned carriage bolts into slots of console and tighten flange nuts using 7/16 socket.



Toll Free
1-866-314-5427

For installation assistance please call Technical Support: 1.877.455.6886